

USER MANUAL for digital indicator with serial input

type: **PAD-94D**

firmware version: 1.12 or higher



Read the user's manual carefully before starting to use the unit.
Producer reserves the right to implement changes without prior notice.

CONTENTS

| | |
|---|-----------|
| 1. BASIC REQUIREMENTS AND USER SAFETY | 3 |
| 2. GENERAL CHARACTERISTICS | 4 |
| 3. TECHNICAL DATA | 4 |
| 4. DEVICE INSTALLATION | 5 |
| 4.1. UNPACKING | 6 |
| 4.2. ASSEMBLY | 6 |
| 4.3. CONNECTION METHOD | 7 |
| 4.4. MAINTENANCE | 10 |
| 5. FRONT PANEL DESCRIPTION | 10 |
| 6. PRINCIPLE OF OPERATION | 11 |
| 6.1. DISPLAYING MODE | 11 |
| 6.1.1. SLAVE mode operation | 11 |
| 6.1.2. MASTER mode operation..... | 12 |
| 7. DEVICE PROGRAMMING | 12 |
| 7.1. PROGRAMMING MENU..... | 12 |
| 7.2. PARAMETERS EDITION..... | 13 |
| 7.2.1. Numeric parameters (digit change mode) | 13 |
| 7.2.2. Numeric parameters (slide change mode)..... | 13 |
| 7.2.3. Switch parameters ("LIST" type) | 13 |
| 7.3. MENU DESCRIPTION..... | 14 |
| 7.3.1. "bri" parameter..... | 14 |
| 7.3.2. "SLAv" menu..... | 14 |
| 7.3.3. "mASt" menu | 15 |
| 7.3.4. "rS" menu | 16 |
| 7.3.5. "Scod" parameter..... | 17 |
| 7.3.6. "Edit" parameter..... | 17 |
| 7.3.7. "dEFS" parameter | 17 |
| 7.3.8. "SErv" menu | 17 |
| 7.4. MENU STRUCTURE | 18 |
| 8. THE MODBUS PROTOCOL HANDLING | 19 |
| 8.1. LIST OF REGISTERS..... | 19 |
| 8.2. TRANSMISSION ERRORS DESCRIPTION..... | 21 |
| 8.3. DRIVING OF DECADES..... | 22 |
| 8.3.1. Decimal point position and minimal number of digits..... | 22 |
| 8.3.2. Interpretation of registers 10h ... 15h content | 23 |
| 8.3.3. Interpretation of registers 18h ... 1Dh content | 23 |
| 8.3.4. Examples of exploration of registers 02h and 03h..... | 23 |
| 8.3.5. Examples of exploration of registers 10h ... 15h..... | 24 |
| 8.4. EXAMPLES OF QUERY/ANSWER FRAMES | 25 |
| 9. DEFAULT AND USER'S SETTINGS LIST | 27 |

Explanation of symbols used in the manual:



- This symbol denotes especially important guidelines concerning the installation and operation of the device. Not complying with the guidelines denoted by this symbol may cause an accident, damage or equipment destruction.

IF THE DEVICE IS NOT USED ACCORDING TO THE MANUAL THE USER IS RESPONSIBLE FOR POSSIBLE DAMAGES.



- This symbol denotes especially important characteristics of the unit. Read any information regarding this symbol carefully

1. BASIC REQUIREMENTS AND USER SAFETY



- The manufacturer is not responsible for any damages caused by inappropriate installation, not maintaining the proper technical condition and using the unit against its destination.

- Installation should be conducted by qualified personnel. During installation all available safety requirements should be considered. The fitter is responsible for executing the installation according to this manual, local safety and EMC regulations.

- The unit must be properly set-up, according to the application. Incorrect configuration can cause defective operation, which can lead to unit damage or an accident.

- If in the case of a defect of unit operation there is a risk of a serious threat to the safety of people or property additional, independent systems and solutions to prevent such a threat must be used.

- The unit uses dangerous voltage that can cause a lethal accident. The unit must be switched off and disconnected from the power supply prior to starting installation of troubleshooting (in the case of malfunction).

- Neighbouring and mating equipment must meet the requirements of appropriate standards and regulations concerning safety and be equipped with adequate anti-overvoltage and anti-interference filters.

- Do not attempt to disassemble, repair or modify the unit yourself. The unit has no user serviceable parts. Units, in which a defect was stated must be disconnected and submitted for repairs at an authorized service centre.



- In order to minimize fire or electric shock hazard, the unit must be protected against atmospheric precipitation and excessive humidity.

- Do not use the unit in areas threatened with excessive shocks, vibrations, dust, humidity, corrosive gasses and oils.



- Do not use the unit in explosion hazard areas.
- Do not use the unit in areas with significant temperature variations, exposed to condensation or icing.
- Do not use the unit in areas exposed to direct sunlight.
- Make sure that the ambient temperature (e.g. inside the control box) does not exceed the recommended values. In such cases forced cooling of the unit must be considered (e.g. by using a ventilator).



The unit is designed for operation in an industrial environment and must not be used in a household environment or similar.

2. GENERAL CHARACTERISTICS

The **PAD-94D** is a simple digital panel indicator intended for displaying any numerical values and characters defined by user (in SLAVE mode only) sent from the master device over the RS-485 serial interface link. The display brightness can be adjusted in 8 steps. Modbus RTU protocol is used to communication with device. Baud rate is user defined in 1200 ÷ 115200 baud range. It is possible to order device with other communication protocol using RS-485 interface (special order required).

3. TECHNICAL DATA

| | |
|--|--|
| Power supply voltage (depending on version) | 85... 230 ...260 V _{AC/DC} ; 50 ÷ 60 Hz |
| External fuse (required) | or 19... 24 ...50 V _{DC} ; 16... 24 ...35 V _{AC} |
| Power consumption | T - type, max. 2 A max. 4.5 VA @ 85 ÷ 260 V _{AC/DC} max. 4.5 VA @ 16 V ÷ 35 V _{AC} max. 4.5 W @ 19 V ÷ 50 V _{DC} |
| Power supply output | 24 V + 5 %, -10 % / max. 100 mA, stabilized |
| Display range | numerical and alphanumeric messages possible to show on 7-segment display |
| Communication interface | RS-485, 8N1 and 8N2, Modbus RTU, not separated |
| Baud rate | 1200 bit/sec ÷ 115200 bit/sec |
| Display (depending on version) | 4 decades: LED, 4 x 20 mm, red 6 decades: LED, 6 x 13 mm, red |
| Data memory | non-volatile memory, EEPROM type |
| Protection level | IP 65 (from front, after using waterproof cover) IP 40 (from front) IP 20 (housing and connection clips) |

| | |
|--------------------------------|---|
| Housing type | panel |
| Housing material | NORYL - GFN2S E1 |
| Housing dimensions | 96 x 48 x 100 mm |
| Mounting hole | 90.5 x 43 mm |
| Assembly depth | min. 102 mm |
| Panel thickness | max. 5 mm |
| Operating temperature | 0 °C to +50 °C |
| Storage temperature | -10 °C to +70 °C |
| Humidity | 5 to 90 % no condensation |
| Altitude | up to 2000 meters above sea level |
| Screws tightening max. torque | 0.5 Nm |
| Max. connection leads diameter | 2.5 mm ² |
| Safety requirements | according to: PN-EN 61010-1 installation category: II pollution degree: 2 voltage in relation to ground: 300 V _{AC} insulation resistance: >20 MΩ insulation strength between power supply and input/output terminal: 1 min. @ 2300 V according to: PN-EN 61326 |
| EMC | |



This is a class A unit. In housing or a similar area it can cause radio frequency interference. In such cases the user can be requested to use appropriate preventive measures.

4. DEVICE INSTALLATION

The unit has been designed and manufactured in a way assuring a high level of user safety and resistance to interference occurring in a typical industrial environment. In order to take full advantage of these characteristics installation of the unit must be conducted correctly and according to the local regulations.



- Read the basic safety requirements on page 3 prior to starting the installation.
- Ensure that the power supply network voltage corresponds to the nominal voltage stated on the unit's identification label.
- The load must correspond to the requirements listed in the technical data.
- All installation works must be conducted with a disconnected power supply.
- Protecting the power supply clamps against unauthorized persons must be taken into consideration.

4.1. UNPACKING

After removing the unit from the protective packaging, check for transportation damage. Any transportation damage must be immediately reported to the carrier. Also, write down the unit serial number on the housing and report the damage to the manufacturer.

Attached with the unit please find:

- user's manual,
- warranty,
- assembly brackets - 2 pieces.

4.2. ASSEMBLY



- The unit is designed for mounting indoor inside housings (control panel, switchboard) assuring appropriate protection against electric impulse waves. Metal housing must be connected to the grounding in a way complying with the governing regulations.

- Disconnect the power supply prior to starting assembly.

- Check the correctness of the performed connections prior to switching the unit on.



In order to assembly the unit, a 90.5 x 43 mm mounting hole (Figure 4.1) must be prepared. The thickness of the material of which the panel is made must not exceed 5 mm. When preparing the mounting hole take the grooves for catches located on both sides of the housing into consideration (Figure 4.1). Place the unit in the mounting hole inserting it from the front side of the panel, and then fix it using the brackets (Figure 4.2). The minimum distances between assembly holes' axes - due to the thermal and mechanical conditions of operation - are 115 mm x 67 mm (Figure 4.3).




Figure 4.1. Mounting hole dimensions




Figure 4.2. Installing of brackets, and dimensions of connectors.




Figure 4.3. Minimum distances when assembly of a number of units

4.3. CONNECTION METHOD

Caution



- Installation should be conducted by qualified personnel. During installation all available safety requirements should be considered. The fitter is responsible for executing the installation according to this manual, local safety and EMC regulations.
- The unit is not equipped with an internal fuse or power supply circuit breaker. Because of this an external time-delay cut-out fuse with minimal possible nominal current value must be used (recommended bipolar, max. 2 A) and a power supply circuit-breaker located near the unit. In the case of using a monopolar fuse it must be mounted on the phase cable (L).
- The power supply network cable diameter must be selected in such a way that in the case of a short circuit of the cable from the side of the unit the cable shall be protected against destruction with an electrical installation fuse.



- Wiring must meet appropriate standards and local regulations and laws.
- In order to secure against accidental short circuit the connection cables must be terminated with appropriate insulated cable tips.
- Tighten the clamping screws. The recommended tightening torque is 0.5 Nm. Loose screws can cause fire or defective operation. Over tightening can lead to damaging the connections inside the units and breaking the thread.
- In the case of the unit being fitted with separable clamps they should be inserted into appropriate connectors in the unit, even if they are not used for any connections.
- **Unused clamps (marked as n.c.) must not be used for connecting any connecting cables (e.g. as bridges), because this can cause damage to the equipment or electric shock.**
- If the unit is equipped with housing, covers and sealing packing, protecting against water intrusion, pay special attention to their correct tightening or clamping. In the case of any doubt consider using additional preventive measures (covers, roofing, seals, etc.). Carelessly executed assembly can increase the risk of electric shock.
- After the installation is completed do not touch the unit's connections when it is switched on, because it carries the risk of electrical shock.

Due to possible significant interference in industrial installations appropriate measures assuring correct operation of the unit must be applied. To avoid the unit of improper indications keep recommendations listed below.

- Avoid common (parallel) leading of signal cables and transmission cables together with power supply cables and cables controlling induction loads (e.g. contactors). Such cables should cross at a right angle.
- Contactor coils and induction loads should be equipped with anti-interference protection systems, e.g. RC-type.
- Use of screened signal cables is recommended. Signal cable screens should be connected to the earthing only at one of the ends of the screened cable.
- In the case of magnetically induced interference the use of twisted couples of signal cables (so-called "spirals") is recommended. The spiral (best if shielded) must be used with RS-485 serial transmission connections.
- In the case of interference from the power supply side the use of appropriate anti-interference filters is recommended. Bear in mind that the connection between the filter and the unit should be as short as possible and the metal housing of the filter must be connected to the earthing with largest possible surface. The cables connected to the filter output must not run in parallel with cables with interference (e.g. circuits controlling relays or contactors).

Connections of power supply voltage and measurement signals are executed using the screw connections on the back of the unit's housing.




Figure 4.4. Method of cable insulation replacing and cable terminals



All connections must be made while power supply is disconnected!




Figure 4.5. Terminals description




Figure 4.6. Connection of power supply

4.4. MAINTENANCE

The unit does not have any internal replaceable or adjustable components available to the user. Pay attention to the ambient temperature in the room where the unit is operating. Excessively high temperatures cause faster ageing of the internal components and shorten the fault-free time of unit operation.

In cases where the unit gets dirty do not clean with solvents. For cleaning use warm water with small amount of detergent or in the case of more significant contamination ethyl or isopropyl alcohol.




Using any other agents can cause permanent damage to the housing.



Product marked with this symbol should not be placed in municipal waste. Please check local regulations for disposal and electronic products.

5. FRONT PANEL DESCRIPTION



Symbols and functions of push-buttons:



Symbol used in the manual: **[ESC/MENU]**

Functions:

- Enter to main menu (press and hold by at least 2 sec.)
- Exit the current level and Enter to previous menu (or displaying mode)
- Cancel the changes made in parameter being edited



Symbol used in the manual: **[ENTER]**

Functions:

- Start to edit the parameter
- Enter to the sub-menu
- Confirmation of changes made in parameter being edited



Symbol used in the manual: [^] [v]

Functions:

- Change of the present menu,
- Modification of the parameter value,
- Change of the display mode.

6. PRINCIPLE OF OPERATION

After turning the power supply on, device ID and software version are showed on the display, next the digital indicator goes to the display mode.

6.1. DISPLAYING MODE

Directly after enter to displaying mode, device displays “- - -” info as long as first actualization of displayed value via RS-485 interface comes. Depend on value of “**mode**” parameter of “**rS**” menu, device can works as MASTER or SLAVE. In SLAVE mode displayed value, and it is parameters are determined by values written to internal registers by other MASTER. In MASTER mode device reads values to displaying, and it is decimal point position from selected SLAVE device.

If content of displayed value register exceeds **permissible displaying range** following message is showed:

- “**ovH**” - if content displayed value register exceeds upper border of **permissible displaying range**
- “**ovL**” - if content displayed value register is smaller than lower border of **permissible displaying range**

Permissible displaying range depends on number of available decades and equals:

- -999 ÷ 9999 for devices equipped with 4 decades,
- -99999 ÷ 999999 for devices equipped with 6 decades.

All accessible parameters can be changed by entering the menu (see: **DEVICE PROGRAMMING**). Use the local keyboard or the remote controller to do it. (Note: all parameters can be remote changed via RS-485 interface).



Configuration of the device (via menu or RS-485 interface) **do not stops device.**

6.1.1. SLAVE mode operation

In SLAVE mode device displays “- - - -” info as long as first write to displayed value registers by MASTER device comes over RS-485 interface. If new value will not be written in this register in time defined by “**mbtO**” parameter since last writing, currently displayed value starts blinking. It stops blinking after next proper write. SLAVE mode allows display user defined signs on selected positions (see: **DRIVING OF DECADES**, page 22). Parameters connected with SLAVE mode are accessible in menu “**SLAv**”, which is displayed only if SLAVE mode is selected (see “**mode**” parameter in “**rS**” menu).

6.1.2. MASTER mode operation

In MASTER mode device displays “- - -” info as long as first read of selected registers of SLAVE device occurs. If SLAVE device do not responds during time defined by “**mbtO**” parameter, since MASTER sent last frame, currently displayed value starts to blinking. Blinking stops after next proper read of selected register of SLAVE device.

Registers of SLAVE device are read every time defined by parameter “**PEr**”. Parameters connected with MASTER are accessible in menu “**mASt**”, which is displayed only if MASTER mode is selected (see “**mode**” parameter in “**rS**” menu).

7. DEVICE PROGRAMMING

The device menu allow user to set all parameters connected to operation of the display, control modes, communication via RS-485 and access settings. The meaning of the particular parameters is described in paragraph **MENU DESCRIPTION**.

7.1. PROGRAMMING MENU

To enter main menu (being in the displaying mode) operator must to press and hold at least 2 sec. **[ESC/MENU]** button.

If the user password is defined (see parameter “**Scod**”), operator have to enter correct one before proceeding to menu options. Entering of the passwords is similar to the edition of numeric parameters (see: **PARAMETERS EDITION**), however presently editing digit is showed only on the display, other digits are replaced by “.” sign.

After entering of last digit of the password first menu position will be displayed (if the password is correct) or warning “**Err**” in other case.

Functions of the buttons while sub-menu and parameters choice:



Selection of sub-menu or parameter for editing. Name of selected item (sub-menu or parameter) is displayed.



Operation of **[ENTER]** button depend on present menu position:

- if the name of some sub-menu is displayed - enter this sub-menu; name of the first parameter (or next level sub-menu) is displayed.
- if the name of some parameter is displayed - enter the edition of this parameter; present value of the parameter is displayed.



[ESC/MENU] button allow user to exit present menu level and goes to upper level menu (or displaying mode).



After about 1 min. since last use of the buttons, device exits the menu mode and returns to the displaying mode (only if no parameters are in editing mode).

7.2. PARAMETERS EDITION

To start edition of any parameter user should select name of desired one using [^] [v] buttons and then press [ENTER].

7.2.1. Numeric parameters (digit change mode)

Numerical parameters are displayed as decimal numbers. The mode of its new value entering depends on chosen edit method (see parameter "Edit").

In mode "by digit" ("Edit"="dig") pressing one of the keys [^] or [v] causes change of current position (flashing digit) or the sign (+/-). Short pressing of the [ENTER] button causes change of the position (digit).

Press [ENTER] at least 2 seconds to accept the changes, after that question "Set?" is displayed, and user must to confirm (or cancel) the changes. To conform changes (and story it in EEPROM) press [ENTER] button shortly after "Set?" is displayed. To cancel the changes press [ESC] button shortly after "Set?" is displayed. After that device returns to the menu.

7.2.2. Numeric parameters (slide change mode)

In "slide change" mode ("Edit"="Slid"), buttons [^] and [v] has different functions.

To increase edited value press (or press and hold) [^] button only, the increasing became quickest as long as button [^] is pressed. To slow down the increasing, button [v] can be used. If [v] is pressed shortly (and button [^] is still pressed), increasing slow down for a moment only, if [v] is pressed and held while button [^] is still pressed the increasing slow down and will be kept on lower speed.

To decrease edited value press (or press and hold) [v] button only. The decreasing became quickest as long as button [v] is pressed. To slow down the decreasing, button [^] can be used. If [^] is pressed shortly (and button [v] is still pressed), decreasing slow down for a moment only, if [^] is pressed and held while button [v] is still pressed the decreasing slow down and will be kept on lower speed.

Press [ENTER] at least 2 seconds to accept the changes, after that question "Set?" is displayed, and user must to confirm (or cancel) the changes. To conform changes (and story it in EEPROM) press [ENTER] button shortly after "Set?" is displayed. To cancel the changes press [ESC] button shortly after "Set?" is displayed. After that device returns to the menu.

7.2.3. Switch parameters ("LIST" type)

Switch parameters can be described as a sets of values (a lists) out of which only one of the options available on the list can be selected for the given parameter. Options of switching parameter are selected using [^], [v] keys.

Short pressing of [ENTER] causes in displaying of the acknowledge question ("Set?"). If key [ENTER] is pressed again, the changes are accepted, stored in EEPROM end the edition process finished. Pressing the key [ESC] after "Set?" causes in cancelling of made changes and returning to menu.

Functions of buttons when editing numeric and switching parameters:



While editing numeric parameter:

- change of current (flashing) digit
- slide change of value (acceleration, deceleration, direction change)

While editing switch parameter - selection of switch parameter.



If numerical parameter is being edited, a short press of **[ENTER]** button change edited position. A long press of **[ENTER]** button (at least 2 sec.) causes of display a “**SEt?**” ask, which allow user to make sure if change of the parameter value is correct. If switch parameter is being edited, a short press of **[ENTER]** button causes of display a “**SEt?**” ask. When **[ENTER]** button is pressed again (while “**SEt?**” is displayed) the new value of the parameter is stored in EEPROM memory.



Pressing this button operator can cancel the changes done up to now (if they were not approved by **[ENTER]** button after the “**SEt?**” ask) and come back to menu.

7.3. MENU DESCRIPTION

“- - - -” - password checking. If some password different from “**0000**” is set, then every enter to main menu follows the entering of password. If entered password is correct then first menu position will be displayed else warning “**Err**”, and unit returns to displaying mode.



Due to problem with direct displaying of “**m**” letter, it is exchanged with special signs “**ñ**”. Independently in user manual letters “**m**” is used to make it more readable (example: “**modE**”).

7.3.1. “bri” parameter

This parameter allows user to set bright of the LED display, bright can be set to conventional values from “**bri1**” to “**bri8**”.

7.3.2. “SLAv” menu

This menu is accessible only if SLAVE mode is selected, and it contains parameters connected with this mode:

“**Addr**” - this parameter defines the address of the device, accordingly to Modbus protocol. It can be set in range from 0 to 199. If the value 0 is set then device, responds to frames with address 255 (FFh).



In SLAVE mode every **PAD-94D** connected to the same serial network should have its own address, different from other devices addressed.

- “tyPE”** - type of value written to displayed value registers, it can be set to:
- “U-16”** - unsigned 16 bit (write to register 01h is not necessary);
 - “S-16”** - signed 16 bit (write to register 01h is not necessary);
 - “U-32”** - unsigned 32 bit (writes to registers 01h and 02h are necessary);
 - “S-32”** - signed 32 bit (writes to registers 01h and 02h are necessary);

- “mbAc”** - this parameter sets the access to the configuration registers of the device.
Possible values:
- “on”** - configuration registers can be set via RS-485 interface,
 - “oFF”** - configuration registers cannot be set via RS-485 interface.



Blockade of writing do not refers with registers no. 01h, 02h i 03h (see: **LIST OF REGISTERS**).

- “vALr”** - this parameter defines reaction for writes to registers 01h, 02h and 03h, it can be set to:
- “on”** - after writes device responds with standard frame
 - “oFF”** - after writes device do not sends anything.



If parameter **“vALr”** is set to **“oFF”**, then it is possible to drive many devices simultaneously (at the same moments), without collisions in network.

7.3.3. “mASt” menu

This menu is accessible only if MASTER mode is selected, and it contains parameters connected with this mode:

- “Addr”** - this parameter defines the address of the device which have to be read. It can be set in range from 0 to 199. If the value 0 is set then device with address 255 (FFh) will be read.
- “rEG”** - this parameter defines holding register number (of SLAVE device), which contains displayed value. If displayed value type is set as 32 bits (signed or unsigned – see parameter **“tyPE”**), parameter **“rEG”** defines higher word register address. Its value can be changed from 0 to 9999.
- “tyPE”** - type of value written to displayed value registers, it can be set to:
- “U-16”** - unsigned 16 bit (single register);
 - “S-16”** - signed 16 bit (single register);
 - “U-32”** - unsigned 32 bit (two following registers);
 - “S-32”** - signed 32 bit (two following registers);
- “Pnt”** - decimal point position, following values are possible for this parameter
“ 0”, “ 0.0”, “ 0.00”, ..., “rEG ”.
If value **“rEG”** is selected, then decimal point position will be read from holding register defined by parameter **“PrEG”** of SLAVE device defined by parameter **“Addr”**

- “PrEG”** - this parameter defines holding register number (of SLAVE device) which contains decimal point position. Value of this parameter matters only if parameter **“Pnt”** is set to value **“rEG”**. In other case value of **“PrEG”** does not matter.
- “PEr”** - this parameter defines time period between successive reads of displayed value and decimal point position (if **“Pnt”**=**“rEG”**) registers.

7.3.4. “rS” menu

This menu is connected with RS-485 interface, and sets his properties:

- “modeE”** - this parameter defines device operation mode. There are available two modes:
- “mASt”** - MASTER mode operation. **PAD-94D** unit reads necessary data from defined registers of SLAVE device. All parameters referred with this operation mode are available in **“mASt”** submenu.
 - “SLAv”** - SLAVE mode operation, **PAD-94D** unit waits for data from MASTER device. All parameters referred with this operation mode are available in **“SLAv”** submenu.
- “bAud”** - this parameter determines RS-485 interface baud rate. It can be set to one of 8 possible values: **“1.2”**, **“2.4”**, **“4.8”**, **“9.6”**, **“19.2”**, **“38.4”**, **“57.6”**, **“115.2”**, which respond to the baud rates of 1200, 2400, 4800, 9600, 19200, 38400, 57600 and 115200 bit/sec respectively.
- “mbtO”** this parameter defines maximal time (sec) between following frames received by the device. If the delay will be greater than the value of **“mbtO”** parameter, displayed value starts blinking. Parameter **“mbtO”** can be set to values from 0 to 99 seconds. The value 0 means that the time will be not controlled.



In MASTER mode, time period defined by parameter **“mbtO”** is prolonged of value defined by parameter **“PEr”**.

- “rESP”** - this parameter defines minimal (additional) delay between the Modbus message and the answer of the device (received and sent via RS-485 interface). This additional delay allows the device to work with poor RS-converters which do not works properly on baud rates higher than 19200. This parameter can be set to one of values:

- | | |
|---------------|---|
| “Std” | - answer as quick as possible, no additional delay |
| “10c” | } - answer delayed of 10, 20, 50, 100 of 200 chars respectively, where one character time depends on selected baud rate |
| “20c” | |
| “50c” | |
| “100c” | |
| “200c” | |



In the most cases parameter **“rESP”** should be set to **“Std”** (no additional delay). Unfortunately for some third party RS-converters **“rESP”** should be adjusted experimentally. Table 7.1 contains most frequently used values.

| | | | |
|-------------------------|--------|--------|---------|
| “bAud” parameter | “38.4” | “57.6” | “115.2” |
| “rESP” parameter | “10c” | “20c” | “50c” |

Tab.7.1. Settings of “rESP” parameter

7.3.5. “Scod” parameter

This parameter defines user password (4-digits number). If this parameter is set at value “0000”, user password is turned off.

If the user do not remember his password, the access to the menu is possible by the “one-use password”. To get this password please contact with Marketing Division. “Single use password” can be used only one time, after that it is destroyed. Entering this password causes in clearing of user password, it means sets the user password to “0000”.



The “one-use password” can be used **ONE TIME ONLY**, it is impossible to use it again! The “one-use password” can be restored by Service Division only.

7.3.6. “Edit” parameter

This parameter allows to change the edition mode of numerical parameters:

- “dig” - the change to “by digit” mode,
- “Slid” - slide change mode.


7.3.7. “dEFS” parameter

This setting allows to restore the factory settings of the device. To get the access to this option special password is required: “5465”, next the device displays acknowledge question “SEt?”. Press [ENTER] to acknowledge the restoring of factory settings or [ESC] to cancel.

7.3.8. “SErv” menu

This menu contains the parameters for authorized service only. To enter this menu proper service password must be entered. Improper settings can causes of damage of the device.

7.4. MENU STRUCTURE



8. THE MODBUS PROTOCOL HANDLING

Transmission parameters: 1 start bit, 8 data bits, 1 or 2 stop bit (2 bits are send, 1 and 2 bits are accepted when receive), no parity control
 Baud rate: selectable from: 1200 to 115200 bits/sec
 Transmission protocol: MODBUS RTU compatible

The device parameters and display value are available via RS-485 interface, as HOLDING-type registers (numeric values are given in U2 code) of Modbus RTU protocol. The registers (or groups of the registers) can be read by 03h function, and wrote by 06h (single registers) or 10h (group of the registers) accordingly to Modbus RTU specification. Maximum group size for 03h and 10h functions cannot exceeds 16 registers (for single frame).



The device interprets the broadcast messages, but then do not sends the answers.

8.1. LIST OF REGISTERS

| Register | Write | Range | Register description |
|----------|-------|------------|---|
| 01h | Yes | see descr. | Displayed value – higher word. |
| 02h | Yes | | <p>Warning! To change displayed value it is required to write data in following manner: first higher word and next lower word of data. Writing of higher word only do not causes changes in displayed data.</p> <p>Displayed value - lower word. Total value of registers 01h and 02h: from -999 to 9999 (for 4 decade version) or from -99999 to 999999 (for 6 decade version); data type depends on parameter “tyPE” of “SLAv” submenu.</p> |
| 03h | Yes | see descr. | <p>Higher byte – displaying mode of registers 01h i 02h content: 00h – display value of registers 01h i 02h as a digits, with control of range. If allowable range (from -999 to 9999 for 4 decade version or from -99999 to 999999 for 6 decade version) is exceeded then proper warning is displayed (“ovH” or “ovL”); 80h – display “-Hi-” rather than value of registers 01h i 02h; 40h – display “-Lo-” rather than value of registers 01h i 02h;</p> <p>Lower byte: bit 7 - reserved bits 6..4 - minimal number of displayed digits. 0 - one digit; 1 - two digits; etc. (see Tab. 8.1). If content of registers 01h and 02h is shorter than minimal number of digits, then additional 0's are displayed. bit 3 - display decimal point on most right position regardless of bits 2..0 value bits 2..0 – decimal point position: 0 – no decimal point; 1 - “ 0.0”; 2 - “ 0.00”; etc.</p> |
| 04h | Yes | see descr. | <p>Lower byte – shift of displayed value to the left of the display - bits 3..0 defines shift size (0 – no shift; 1 – one position; etc.)</p> |

| Register | Write | Range | Register description |
|------------------|--------------|----------------|--|
| 05h | Yes | see descr. | Higher byte - activation of LED's blinking (about 1 Hz), bit 7 - first LED from the left; bit 6 - second LED from the left; etc. Lower byte - activation of LED's light, bit 7 - first LED from the left; bit 6 - second LED from the left; etc. |
| 10h | Yes | see descr. | Lower byte: Sign defined for decade no. 1 (most right) (see Tab. 8.2); in ASCII mode – its value select sign of ASCII table; in bit mode: bit 0 - segment A,... bit 6 - segment G, bit 7 – DP, Higher byte: bit 7 – enable displaying of defined sign in place of digit of decade 1; bit 6 – ASCII coding enable other bits - reserved |
| 11h | Yes | see descr. | Like above, but refers to decade 2 |
| 12h | Yes | see descr. | Like above, but refers to decade 3 |
| 13h | Yes | see descr. | Like above, but refers to decade 4 |
| 14h | Yes | see descr. | Like above, but refers to decade 5 (for 6 decade version only) |
| 15h | Yes | see descr. | Like above, but refers to decade 6 (for 6 decade version only) |
| 18h | Yes | see descr. | Attributes of decade 1 (most right , see Tab. 8.3); bit 15 - if this bit is set then global " col " parameter will be used instead of bits 3..0 to determine decade colour bit 12 - blinking enable (about 1 Hz) bit 3..0 - decade colour other bits - reserved |
| 19h | Yes | see descr. | Like above, but refers to decade 2 |
| 1Ah | Yes | see descr. | Like above, but refers to decade 3 |
| 1Bh | Yes | see descr. | Like above, but refers to decade 4 |
| 1Ch | Yes | see descr. | Like above, but refers to decade 5 (for 6 decade version only) |
| 1Dh | Yes | see descr. | Like above, but refers to decade 6 (for 6 decade version only) |
| 20h ¹ | Yes | 01h÷FFh | Device address in SLAVE mode. |
| 21h | No | 20E8h 20EEh | Device identification code (ID for 4 decade version) Device identification code (ID for 6 decade version) |
| 22h ² | Yes | 0÷7 | " bAud " parameter in " rS " menu (baud rate); 0 - 1200 baud; 1 - 2400 baud; 2 - 4800 baud; 3 - 9600 baud; 4 - 19200 baud; 5 - 38400 baud; 6 - 57600 baud; 7 - 115200 baud |
| 23h ³ | Yes | 0 ÷ 1 | " mbAc " parameter in " SLAv " menu (permission to write registers via RS-485 interface); 0 - write denied ; 1 - write allowed |
| 25h | Yes | 0 ÷ 5 | " rESP " parameter in " rS " menu (additional response delay); 0 - no additional delay; 1 - " 10c " option; 2 - " 20c " option; 3 - " 50c " option; 4 - " 100c " option; 5 - " 200c " option; |
| 26h | Yes | 0 ÷ 1 | " vALr " parameter in " SLAv " menu (blockade of modbus answer , after writes to registers 01h, 02h or 03h); 0 – answer blocked; 1 – standard modbus answer |

| Register | Write | Range | Register description |
|------------------|--------------|--------------|---|
| 27h | Yes | 0 ÷ 99 | “ mbtO ” parameter in “ rS ” menu (maximum delay between received frames); 0 - no delay checking; 1 ÷ 99 - maximum delay expressed in seconds |
| 2Dh ⁴ | Yes | 1 ÷ 8 | “ brI ” parameter (display brightness); 1 - the lowest brightness; 8 - the highest brightness |
| 2Fh | Yes | 0 ÷ 1 | “ Edit ” parameter (numerical parameters edit mode); 0 - “ dig ” mode; 1 - “ SLid ” mode |
| 30h | Yes | 0 ÷ 3 | “ tyPE ” parameter in “ SLAv ” menu (displayed value type): 0 - unsigned 16 bit (write to register 01h is not necessary); 1 - signed 16 bit (write to register 01h is not necessary); 2 - unsigned 32 bit (writes to registers 01h and 02h are necessary); 3 - signed 32 bit (writes to registers 01h and 02h are necessary); |
| 31h ⁴ | Yes | 1 ÷ 8 | Dynamically driving of display brightness via serial interface |

- ¹ - after writing to register no 20h the device responds with an “old” address in the message.
² - after writing to register no 22h the device responds with the new baud rate.
³ - the value of the “**mbAc**” parameter is also connected to write to this register, so it is possible to block a writes, but impossible to unblock writes via RS-485 interface, The unblocking of the writes is possible from menu level only.
⁴ - if often changing of display brightness is required, writing to register 31h is recommended. Contents of this register is not stored while power off, and after power on parameter set via MENU is used for display brightness (register 2Dh)

8.2. TRANSMISSION ERRORS DESCRIPTION

If an error occurs while write or read of single register, then the device sends an error code according to Modbus RTU specifications.

Error codes:

- 01h** - illegal function (only functions 03h, 06h and 10h are available),
02h - illegal register address
03h - illegal data value
08h - no write permission (see: “**mbAc**” parameter)

8.3. DRIVING OF DECADES



- Driving of decades described below is possible in SLAVE mode only
- Number of available decades depends on device type




Figure 8.1. Decades positions for 6 decade version

8.3.1. Decimal point position and minimal number of digits

| Bits 6..0 of register. 03h (example value) | Displayed message if "displayed value" equals 1 | Displayed message if "displayed value" equals 123 |
|---|--|--|
| 000 0000 | 1 | 123 |
| 000 0001 | 0.1 | 12.3 |
| 000 0010 | 0.01 | 1.23 |
| 000 0011 | 0.001 | 0.123 |
| 000 1xxx | 1. | 123. |
| 010 0000 | 01 | 123 |
| 010 0001 | 0.1 | 12.3 |
| 010 0010 | 0.01 | 1.23 |
| 010 1xxx | 01. | 123. |
| 100 0000 | 0001 | 0123 |
| 100 0001 | 000.1 | 012.3 |
| 100 0010 | 00.01 | 01.23 |
| 100 1xxx | 0001. | 0123. |


x - does not matter

Tab. 8.1. Decimal point position and minimal number of digits

8.3.2. Interpretation of registers 10h ...15h content

- Con** - if this bit is set (1) then, sign defined by bits **7..0** is displayed in place of particular digit (defined as a part of registers 01h and 02h value),
- Asc** - if this bit is set then sign to be placed on particular decade (defined by bits **7..0**) is interpreted as ASCII code,
- X** - these bits does not matter
- DP, G...A** - these bits defines if particular segments light or not (only if bit **Asc=0**) or ASCII code of particular decade (only if bit **Asc=1**).

| | | | | | | | | | | |
|-----------|-----------|--------------|----------|----------|----------|----------|----------|----------|----------|----------|
| 15 | 14 | 13..8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Con | Asc | X | DP | G | F | E | D | C | B | A |



Tab. 8.2. Interpretation of registers 10h ...15h content

8.3.3. Interpretation of registers 18h ... 1Dh content

- Aon** - if this bit is set then the colour of decade character is determined with **Co** bits. In the other case the colour of decade character is determined with “**Col**” parameter (available in device menu).
- X** - these bits does not matter
- BL** - if this bit is set then particular decade blinks about time per second
- Co** - decade colour, range: from 0 to 8. If **Co** > 8, then decade colour is determined with “**Col**” parameter (available in device menu).



Aon and **Co** bits are important only for devices equipped with multicoloured display.

| | | | | |
|-----------|---------------|-----------|--------------|-------------|
| 15 | 14..13 | 12 | 11..4 | 3..0 |
| Aon | X | BL | X | Co |

Tab. 8.3. Interpretation of registers 18h ... 1Dh content

8.3.4. Examples of exploration of registers 02h and 03h

To display 16 bit signet numbers, with 2 digits after decimal point. Parameter “**tyPE**” of menu “**SLAv**” should be set to “**S-16**” (16 bit signed values). To set decimal point position, the value of register 03h must to be written with value 2 (see Tab. 8.1). Decimal point position can be done once, and it is valid for all further values of reg. 01h and 02h.

To set displayed value, its value must to be written to register 01h and 02h, e.g.


- by writing of 0010h (+16 decimal) to register 02h (reg. 01H = 0000h) causes by displaying:



- by writing values higher than **permissible displaying range** causes by displaying:



- by writing values lower than **permissible displaying range** causes by displaying:



Displaying of negative numbers is possible only if proper displaying value data type is selected (“S-32” or “S-16”). Negative values should be written in U2 code.

8.3.5. Examples of exploration of registers 10h ... 15h

To display message like showed hereafter, with assumption that number value (6.5) may be changed (e.g. depend on measurement value):



User should set:

1. register 02h to value 0021h (65 decimal)
2. register 03h (decimal point position) to value 0001h (see Tab. 8.1),
3. register 10h (sign in place of decade 1) to value C043h (ASCII code of “C” sign in lower byte and bits **Con** i **Asc** in higher byte, see Tab. 8.2),
4. register 11h (sign in place of decade 2) to value 8063h (byte code of “σ” sign in lower byte, and bit **Con** in higher byte – no ASCII coding - see Tab. 8.2),
5. register 04h (left shift of displayed value) to value 02h (shift of 2 positions to the left).

Writes presented above can be done at once, and it is valid for all further values of reg. 01h and 02h.

To change displayed number (6.5) it is change of register 02h only is necessary (if data type is set to 16 bits), e.g. By writing of value 12 to reg. 02h causes by displaying message:



User must to remember, that signs defined by registers 10h...13h will be displayed in place of particular digits of displayed values, e.g. If in example above user writes value C041h (sign "A" in ASCII code) to register 12h, then device shows message:



8.4. EXAMPLES OF QUERY/ANSWER FRAMES

Examples apply for device with address 1. All values are represent hexadecimal.

Field description:

| | |
|------------------|--|
| ADDR | Device address on modbus network |
| FUNC | Function code |
| REG H,L | Starting address (address of first register to read/write, Hi and Lo byte) |
| COUNT H,L | No. of registers to read/write (Hi and Lo byte) |
| BYTE C | Data byte count in answer frame |
| DATA H,L | Data byte (Hi and Lo byte) |
| CRC L,H | CRC error check (Hi and Lo byte) |

1. Read of device ID code:

| ADDR | FUNC | REG H,L | | COUNT H,L | | CRC L,H | |
|------|------|---------|----|-----------|----|---------|----|
| 01 | 03 | 00 | 21 | 00 | 01 | D4 | 00 |

The answer:

| ADDR | FUNC | BYTE C | DATA H,L | | CRC L,H | |
|------|------|--------|----------|----|---------|----|
| 01 | 03 | 02 | 20 | E8 | A1 | CA |

DATA – identification code (20E8h)

2. Change of the device address from 1 to 2 (write to reg. 20h)

| ADDR | FUNC | REG H,L | | DATA H,L | | CRC L,H | |
|------|------|---------|----|----------|----|---------|----|
| 01 | 06 | 00 | 20 | 00 | 02 | 09 | C1 |

DATA H - 0

DATA L - new device address (2)

The answer (the same as the message):

| ADDR | FUNC | REG H,L | | DATA H,L | | CRC L,H | |
|------|------|---------|----|----------|----|---------|----|
| 01 | 06 | 00 | 20 | 00 | 02 | 09 | C1 |

3. Writing of value to be displayed, and decimal point position (multi register write using modbus function 10h)

| ADDR | FUNC | REG H,L | | COUNT H,L | | BYTE C |
|------|------|---------|----|-----------|----|--------|
| 01 | 10 | 00 | 01 | 00 | 03 | 06 |

And next bytes of frame:

| DATA H1,L1 | | DATA H2,L2 | | DATA H3,L3 | | CRC L,H | |
|------------|----|------------|----|------------|----|---------|----|
| 00 | 00 | 04 | D2 | 00 | 02 | 97 | 8D |

This write causes by displaying message: “12.34”

Device's answer:

| ADDR | FUNC | REG H,L | | COUNT H,L | | CRC L,H | |
|------|------|---------|----|-----------|----|---------|----|
| 01 | 10 | 00 | 01 | 00 | 03 | D1 | C8 |

4. Try to write improper value to register 22h (baud rate).

| ADDR | FUNC | REG H,L | | DATA H,L | | CRC L,H | |
|------|------|---------|----|----------|----|---------|----|
| 01 | 06 | 00 | 22 | 00 | 09 | E9 | C6 |

DATA L – DATA L – value exceeds allowable range (from 0 to 7)

The answer (if an error occur):

| ADDR | FUNC | ERR | CRC L,H | |
|------|------|-----|---------|----|
| 01 | 86 | 03 | 02 | 61 |



There is no full implementation of the Modbus Protocol in the device. The functions presented above are available only.

9. DEFAULT AND USER'S SETTINGS LIST

| <i>Parameter</i> | <i>Description</i> | <i>Default value</i> | <i>User's value</i> | <i>Desc. page</i> |
|--|---|----------------------|---------------------|-------------------|
| bri | Display brightness | bri6 | | 14 |
| Configuration of SLAVE mode (menu "SLAv") | | | | |
| Addr | PAD-94D device address | 0 | | 14 |
| tyPE | Display value type | S-16 | | 15 |
| mbAC | Permission to changes of configuration registers | on | | 15 |
| vALr | Blockade of answer after writes to reg. 01H, 02h or 03h | on | | 15 |
| Configuration of MASTER mode ("mASt" menu) | | | | |
| Addr | SLAVE device address | 0 | | 15 |
| rEG | Number of displayed value register | 1 | | 15 |
| tyPE | Displayed value data type | S-16 | | 15 |
| Pnt | Decimal point position | 0 | | 15 |
| PrEG | Decimal point register number (of SLAVE device) | 5 | | 16 |
| PEr | Time period of data reading from SLAVE device | 0 | | 16 |
| RS-485 interface configuration ("rS" menu) | | | | |
| modE | Operation mode | SLAv | | 16 |
| bAud | Baud rate | 9600 | | 16 |
| mbtO | Maximum delay between received messages | 0 | | 16 |
| rESP | Additional delay of answer transmission | Std | | 16 |
| Configuration of numerical parameters edition | | | | |
| Edit | Numerical parameters edit mode | dig | | 17 |



BD|Sensors GmbH
BD-Sensors-Straße 1
95199 Thierstein, Germany

Telefon +49 (0) 9235 / 9811 - 2099
Telefax +49 (0) 9235 / 9811 - 860

e-mail: info@bdsimex.de
www.bdsimex.de